CCD B/W VIDEO CAMERA MODULE

SONY

# XC-ST50/50CE XC-ST30/30CE



# User's Guide

(Ver. 1.0) — English —

# Table of Contents =

OUTLINE 1
MAIN FEATURES 1
SPECIFICATIONS COMPARISON
SYSTEM CONFIGURATION
MAIN SPECIFICATIONS
CONNECTION DIAGRAM 4
LOCATION OF PARTS AND OPERATION5
PHASE CONDITIONS OF EXTERNAL SYNCHRONIZATION 6
ELECTRONIC SHUTTER7
RESTART RESET (R.R)
FRAME IMAGE OUTPUT WITH STROBE LIGHT 12
OUTPUT WAVEFORM TIMING CHART (XC-ST50 (EIA)/XC-ST30 (EIA))
TIMING CHART OF EXTERNAL TRIGGER SHUTTER - MODE 1 17
TIMING CHART OF EXTERNAL TRIGGER SHUTTER - MODE 2 23
DIMENSIONS
SPECTRAL RESPONSE CHARACTERISTICS (TYPICAL VALUE)
COMPARISON OF SPECTRAL RESPONSE CHARACTERISTICS (TYPICAL VALUE) 26
VARIOUS LENS SELECTION

#### OUTLINE :

The XC-ST50/50CE and XC-ST30/30CE are compact, lightweight, black and white cameras of a new concept, which are produced as input devices for image processing by using the latest technology. These models inherit the basic functions of the XC-75 (installing a 1/2-inch CCD) and the XC-73 (installing a 1/3-inch CCD), which are used in various types of devices and systems and win popularity in the machine vision field. The XC-ST50/50CE and XC-ST30/30CE provides an external trigger shutter that can capture the image of a high-speed moving object using an external signal. This enables a still image to be read in arbitrary timing. These two models are compatible with each other, providing comparable fit and function. The user can select a model according to the conditions of subjects and optical conditions. In addition, the XC-ST50/50CE and XC-ST30/30CE enable functions to be set on the external rear panel for improved operability and have an internal configuration which allows for significant shock and vibration resistance, enabling easy incorporation into machine vision equipment.

# — MAIN FEATURES —

## ■ 1/2", 1/3" IT CCD

# External trigger shutter function

(XC-ST50/ST30: 1/4 to 1/10,000 seconds

XC-ST50CE/ST30CE: 1/4 to 1/8,000 seconds)

Inputting the trigger pulse produces one still image a frame. This feature allows the image of a high speed moving object to be captured.

#### Restart Reset (R.R) function

By inputting the HD and VD signals (2 VD or more) from an external source, control of the CCD exposure time can be performed according to the length between VD pulses.

This function is used for long exposures and strobe with frame image output.

# Synchronization system: Internal/external HD/VD, and VS

(VS is used only during external synchronization.)

Inputting an HD/VD signal from the outside automatically establishes external synchronization.

This function is effective for controlling multiple cameras efficiently from the external system.

# Setting each mode on rear panel:

The setting of each mode can be changed by DIP switches.

Almost all switches are located on the rear panel. This feature allows control settings to be easily made after equipment is installed.

# ■ Compact and lightweight

44 (W)  $\times$  29 (H)  $\times$  57.5 (D) mm

#### C-mount

#### Excellent shock and vibration resistance


70G/10G

# Compatibility

These models are the same size and provide the same functions as the XC-ST70. They can be operated in the same way as the XC-ST70 (installing 2/3-inch CCD). Therefore, they provide high compatibility.

# = SYSTEM CONFIGURATION =

The components making up the system based on XC-ST50/ST50CE or XC-ST30/ST30CE video camera are as follows.



# — SPECIFICATIONS COMPARISON —

	Т		I	
	XC-ST50	XC-75	XC-ST30	XC-73
Image device	1/2-inch interline transfer CCD	1/2-inch interline transfer CCD	1/3-inch interline transfer CCD	1/3-inch interline transfer CCD
Effective picture elements	768 (H) ×494 (V)	768 (H) ×494 (V)	768 (H) ×494 (V)	768 (H) ×494(V)
Lens mount	C mount	C mount	C mount	C mount
Scanning system	2:1 interlaced	2:1 interlaced	2:1 interlaced	2:1 interlaced
Sensitivity	400 lx F8	400 lx F4	400 lx F8	400 lx F4
Minimum	0.3 lx	3.0 lx	0.3 lx	3.0 lx
illumination				
S/N ratio	60db	56db	56db	56db
Normal shutter	1/100 to 1/10,000	1/100 to 1/10,000	1/100 to 1/10,000	1/100 to 1/10,000
External trigger	1/4 to 1/10,000	1/100 to 1/1,600	1/4 to 1/10,000	1/100 to 1/1,600
shutter	Can be changed by the			
	trigger pulse width or rear	trigger and VD. Internal	trigger pulse width or	trigger and VD. Internal
	panel switch.	setting needs to be changed.	rear panel switch.	setting needs to be changed.
Dimensions	44 (W) ×29 (H) ×57.5 (D) mm	44 (W) ×29 (H) ×71 (D) mm	44 (W) ×29 (H) ×57.5 (D) mm	44 (W) ×29 (H) ×71 (D) mm
Mass	110 g	140 g	110 g	140 g
Vibration resistance	10G (in the X, Y, and Z	7G (in the X, Y, and Z	10G (in the X, Y, and Z	7G (in the X, Y, and Z
	directions at 20 to 200 Hz)	directions at 11 to 200 Hz)	directions at 20 to 200 Hz)	directions at 11 to 200 Hz)
Optical	Clear	1R cut off	Clear	1R cut off
Ext. Sync.	1H delay	No delay	1H delay	No delay

# — MAIN SPECIFICATIONS

Image pickup device

XC-ST50/50CE: 1/2-inch interline transfer CCD

XC-ST30/30CE: 1/3-inch interline transfer CCD

Number of effective pixels

XC-ST50/ST30:  $768(H) \times 494(V)$ XC-ST50CE/ST30CE:  $752(H) \times 582(V)$ 

CCD horizontal driving frequency
XC-ST50/ST30: 14.318 MHz
XC-ST50CE/ST30CE: 14.187 MHz

CCD vertical driving frequency
XC-ST50/ST30: 15.734 kHz
XC-ST50CE/ST30CE: 15.625 kHz
Signal system EIA/CCIR

Cell size

XC-ST50: 8.4(H)  $\times$  9.8(V)  $\mu$ m XC-ST50CE: 8.6(H)  $\times$  8.3(V)  $\mu$ m XC-ST30: 6.35(H)  $\times$ 7.4(V)  $\mu$ m XC-ST30CE: 6.5(H)  $\times$ 6.25(V)  $\mu$ m

Lens mount C mount Flange back 17.526 mm

Synchronization system

Internal/external

(Selected automatically)

External sync input/output

HD/VD (2 to 5 Vp-p)

VS (Sync level: 0.3 Vp-p<sup>+0.3V</sup>)
 ★ Automatically selected according to the existence of an input signal when the selection switch on the

rear panel is set to EXT.

Allowable frequency deviation of external synchronization

± 1 %

(in horizontal synchronous frequency)

Non-interlaced

(during external sync input)

Horizontal resolution

XC-ST50/ST30: 570 TV lines XC-ST50CE/ST30CE: 560 TV lines

Sensitivity

XC/ST50/50CE: 400 lx F8 (r=ON,0 dB) XC/ST30/30CE: 400 lx F5.6 (r=ON,0 dB)

S/N ratio

XC-ST50/50CE: 60 dB/58dB XC-ST30/30CE: 56 dB/54dB

Minimum illuminance 0.3 lx (F1.4, AGC ON)
Gain AGC/Manual/Fixed

(Can be selected using the

switch on the rear panel.)

Gamma correction ON/OFF

(Can be selected using the

switch on the rear panel.)

Electronic shutter

XC-ST50/ST30: 1/100 to 1/10,000 seconds XC-ST50CE/ST30CE: 1/120 to 1/10,000 seconds

External trigger shutter

XC-ST50/ST30: 1/4 to 1/10,000 seconds
 XC-ST50CE/ST30CE: 1/4 to 1/8,000 seconds
 Set using the DIP switch on the rear panel, or continuously variable with the trigger pulse width.

Supply voltage +12 VDC (+10.5 V to 15V)
Power consumption XC-ST50/50CE: 2.0 W

XC-ST30/30CE: 1.9 W

Operating temperature -5 °C to +45 °C

Storage temperature -30 °C to +60 °C

Performance assurance temperature

0 °C to +40 °C

Operating humidity 20 to 80 % (Non-condensing) Storage humidity 20 to 95 % (Non-condensing)

Vibration resistance 10G

(For 20 minutes in the X, Y, and Z directions at 20 to 200 Hz)

Shock resistance 70G

Outside dimensions  $44(W) \times 29(H) \times 57.5(D)$  mm

Weight 110 g

Standards UL1492, FCC Class A Digital

Device, and CE (EN50081-2 +

EN50082-2)

AS4251.1 + AS4252.2

Other Restart Reset function

Frame or field integration can be

selected.

Conforms to new 12-pin EIAJ

assignment.


Accessories Lens mount cap (1)

Instruction Manual (1)

#### External synchronization for each mode

Mode		lata wa al ay wa a	External sync		
		Internal sync	HD/VD	VS	
Normal		0	0	0	
Normal shutter		0	0	0	
) ger	Mode 1	0	0	×	
External trigger shutter	Mode 2	Trigger signal generates an internal VD (single) signal.	×	×	
	estart Reset	×	0	×	

# CONNECTION DIAGRAM



Note: All functions of the XC-ST50/50CE and XC-ST30/30CE cannot be used when using DC-777/CE, DC-77RR/CE, and JB-77. Refer to the table shown below.


JB-77 (No trigger input terminal is provided.)

XC-ST50/50CE XC-ST30/30CE	DC-777/CE	DC-77RR/CE	JB-77
Normal	0	0	0
Normal shutter	0	0	0
Restart Reset (R.R)	0	0	0
Restart Reset (R.R) + shutter	0	0	0
External trigger shutter	×	×	×

O: Can be used.

X: Cannot be used.

# LOCATION OF PARTS AND OPERATION =




(11)

(12)

(10)

(9)

412-pin multi-connector



Pin No.	External HD/VD synchronization	Internal HD/VD synchronization	External VS synchronization
1	GND	GND	GND
2	+12 V	+12 V	+12 V
3	GND	GND	GND
4	VIDEO output	VIDEO output	VIDEO output
5	GND	GND	GND
6	External HD input	Internal HD output	_
7	*1 External VD input	Internal VD output	VS
8	GND	GND	GND
9	_	_	_
10	*2 WEN output	*2 WEN output	*2 WEN output
11	TRIG input	TRIG input	TRIG input
12	GND	GND	GND

- \*1: An input VD signal is required when the restart/reset mode is used.
- \*2: A WEN output signal is valid only in the external trigger shutter mode.

#### • Factory-setting mode of rear panel

Corresponding No.	Switch					
6	γ correction ON/OFF selector switch					
7	Internal/external sync selector switch					
8	Trigger polarity selector switch					
9	75 $Ω$ termination selector switch					
	Selection DIP switch					
10	1, 2, 3, 4: Selects the Shutter speed.	OFF				
	5: Selects the field and frame integration.	(All set to				
	6, 7, 8: Selects the normal shutter, external trigger shutter, and restart/reset.	the left.)				
11)	GAIN switch	FIX				

#### (1) Lens mount section

A commercial C-mount lens as well as a Sony standard lens can be used.

#### ② Camera mounting reference hole These screw holes are positioned with high precision related to CCD sensor.

- ③ Screw hole for tripod adaptor mounting (VCT-ST70I)
- 4 12-pin multi-connector DC IN/SYNC (DC power/sync signal input)
- ⑤ BNC connector VIDEO OUT
- δ γ correctionON/OFF selector switch

# ⑦ Internal/external sync selector switch

The camera operates with internal synchronization when there is no external sync input signal in the EXT position. In this case, an HD/VD signal is not output from the 12-pin multi-connector.

# Trigger polarity selector switch This switch can select the polarity (negative or positive) of a trigger pulse.

#### (9) 75 $\Omega$ termination selector switch

#### (10) Selection DIP switch

Switches 1 to 4:

Selects the shutter speed.

Switch 5: Selects the frame or field Switches 6 to 8:

Selects the normal shutter, external trigger shutter, and restart/reset.

#### (1) GAIN switch

- A: Outputs a fixed-level video signal according to the brightness of a subject. (Variable range: 0 to 18 dB)
- F: Fixed gain 0 dB
- M: Variable gain (Manual)
- M (during factory setting):

Adjusted so that all XC-ST50/50CEs or XC-ST30/30CEs are the same in sensitivity (set by Sony's standard value) according to the deviation in sensitivity of CCD.

Valid when multiple XC-ST50/50CEs or XC-ST30/30CEs are used for an identical subject.

#### 12 Volume control switch

This switch can be changed in the range of 0 to 18 dB when the GAIN switch is set to "M".

During factory setting, this switch is adjusted to the fixed sensitivity for a standard subject.

# = PHASE CONDITIONS OF EXTERNAL **SYNCHRONIZATION**

#### External synchronization for each mode

For normal video/normal shutter


Continuous HD/VD signal (should conform to EIA and CCIR frequencies in the timing shown in the figure below.)

For Restart Reset (RR)/external trigger shutter

Continuous HD signal. The phase between VD (reset) and HD signals is as specified in the figure below in any timing.

#### Phase conditions

The phase relation between external input HD and VD signals should be set as shown below with respect to the specified center phase.



1 CLK = 69.84 n sec (XC-ST50/ST30)

The operation in parentheses refers to XC-ST50CE/ST30CE.


= 70.48 n sec (XC-ST50CE/ST30CE)

Note: The synchronized VD signals are delayed for 1H at HD/VD external synchronization mode, while there is no VD signal delay at VS external synchronization mode.

# **ELECTRONIC SHUTTER**

Two types of electronic shutter are provided: normal shutter and external trigger shutter. The electronic shutter speed and type can be set using the DIP switch on the rear panel.

#### ■ DIP switch on the rear panel



#### Normal shutter

This mode provides continuous video output with the electronic shutter selected by switches to clearly capture the image of a high-speed moving object.

#### **♦ Setting of normal shutter speed**

Switch	Shutter Off	1/125	1/250	1/500	1/1000	1/2000	1/4000	1/10000	*Flickerless	
1	0	1	0	1	0	1	0	1	_	
2	0	0	1	1	0	0	1	1		* In the flickerless mode, the normal
3	0	0	0	0	1	1	1	1	-	shutter
4	0	0	0	0	0	0	0	0	1	speed is 1/100 sec for
5		Frame: 0 / Field: 1								XC-ST50/ST30 (EIA)
6	_	_	_	_	_	_	_	_	-	1: ON
7	-	_	_	_	_	_	_	_	1	0: OFF
8	-	-	-	-	_	_	_	-	-	-: Either ON or OFF

Note: It is recommended to set DIP switch 5 for field selection. (The field selection is about two times higher in sensitivity than frame selection.)

#### ELECTRONIC SHUTTER :

#### External trigger shutter

By inputting an external trigger, the image of a high-speed moving object can be captured in an exact position. Set DIP switches 6, 7, and 8 on the rear panel to mode 1 or 2. (Refer to the table below.)

When the trigger pulse width is 1/3 sec or more, the camera switches to normal (continuous) video operation.

There are two modes for timing in which a video signal is obtained.

#### Mode 1 (Non-reset mode)

In this mode, an output video signal is synchronized with the VD signal after the triggered exposure is complete.

- An output video signal synchronized with the external VD signal when an external HD/VD signal is input.
- An output video signal synchronized with an internal VD signal when no external HD/VD signal is input.

#### • Mode 2 (Reset mode)

In this mode, a video signal is output soon after exposure is complete.

\* For more details of each timing chart, refer to pages 16 to 23.

#### **♦ Setting of external trigger shutter speed**

There are two ways to set the shutter speed.

#### · Using DIP switch on the rear panel

Mode 1 (Non-reset mode)

Switch	*1/100	1/125	1/250	1/500	1/1000	1/2000	1/4000	**1/10000		
1	_	1	0	1	0	1	0	1		
2	_	0	1	1	0	0	1	1		
3	_	0	0	0	1	1	1	1		
4	1	0	0	0	0	0	0	0		
5		Frame: 0 / Field: 1								
6	0	0	0	0	0	0	0	0		
7	1	1	1	1	1	1	1	1		
8	1	1	1	1	1	1	1	1		

#### Mode 2 (Reset mode)

Switch	*1/100	1/125	1/250	1/500	1/1000	1/2000	1/4000	**1/10000	]		
1	-	1	0	1	0	1	0	1			
2	_	0	1	1	0	0	1	1	۶ [		
3	_	0	0	0	1	1	1	1			
4	1	0	0	0	0	0	0	0			
5		Frame: 0 / Field: 1									
6	0	0	0	0	0	0	0	0	1		
7	0	0	0	0	0	0	0	0	c		
8	1	1	1	1	1	1	1	1	_		

The external trigger shutter speed is set to 1/100 sec for XC-ST50/ST30(EIA) and 1/120 sec for XC-ST50CE/30CE(CCIR).

\*\* The external trigger shutter speed is set to 1/10000 sec for XC-ST50/ST30(EIA) and 1/8000 sec for XC-ST50CE/30CE(CCIR).

1: ON

0: OFF

-: Either ON or OFF

#### · Using trigger pulse width

- Set all DIP switches 1 to 4 on the rear panel to 0.
- An arbitrary shutter speed can be obtained by setting the trigger pulse width to the range of 2 μsec to 250 msec.

Switch	Mode 1 (Non-reset mode)	Mode 2 (Reset mode)			
1	0	0			
2	0	0			
3	0	0			
4	0	0			
5	Frame: 0 / Field: 1				
6	0	0			
7	1	0			
8	1	1			

Exposure time = Trigger pulse width + 97  $\mu$ sec (XC-ST50/ST30) 120  $\mu$ sec (XC-ST50CE/ST30CE)

Note


1: ON 0: OFF

- : 1. It is recommended to set DIP switch 5 for field selection.
  - (The field selection is about two times higher sensitivity than frame selection.)
  - After a trigger pulse is input, a new trigger pulse should not be input before the video signal obtained by the trigger pulse has been output.

#### ELECTRONIC SHUTTER =

#### **♦** Specifications of trigger pulse

When using a trigger pulse like shown below, set the TRIG polarity selector switch on the rear panel to ±:




A: 2 to 5.0 V

B: 0 to 0.6 V

T: 2  $\mu s$  to 1/4 s, 100  $\mu s$  to 1/4 s when setting the shutter speed using DIP switch

When using a trigger pulse like shown below, set the TRIG polarity selector switch on the rear panel to ⊡:




A: 4.0 to 5.0 V

B: 0 to 2.0 V

T: 2  $\mu s$  to 1/4 s, 100  $\mu s$  to 1/4 s when setting the shutter speed using DIP switch

- \* Input impedance: 10 kΩ or more
- \* The voltage and pulse width used are measured at pin 11 of the 12-pin multi-connector on the rear panel.

# ♦ Specifications of WEN (Write ENable Pulse)



T: 15.875 ms (XC-ST50/30), 18.752 ms (XC-ST50CE/30CE)

\* Output impedance: 10 kΩ or more

# **RESTART RESET (R.R)**

The information on one screen can be extracted at any time by inputting a restart/reset signal (HD/VD) from external equipment. To enter this mode, set DIP switches 6, 7, and 8 on the rear panel of the camera as shown in the table below.

Switch	Restart Reset (R.R)	
1	0	
2	0	
3	0	
4	0	
5	0	
6	1	
7	1	1: ON
8	1	0: OFF

#### ♦ Long exposure

Restart Reset is especially effective for Long Exposure.

A clear image is obtained by extending the exposure time of the CCD when satisfactory sensitivity cannot be obtained under ordinary operating conditions or when observing the trail of a moving object.

The exposure time is determined by the period (T) between external VD pulses as follows.


#### Timing and conditions

#### Example 1 of Long Exposure

**EXT HD** Continuous signal: 15.734 kHz (XC-ST50/ST30), 15.625 kHz (XC-ST50CE/30CE) Allowable frequency value  $\pm 1\%$ 



**EXT VD** VD interval(T): 262.5H or more (XC-ST50/ST30), 312.5H or more (XC-ST50CE/30CE) and 1 second or less (Recommended)



Odd and even fields are determined by the phase of the EXT HD/VD signal input from external equipment.


#### RESTART RESET (R.R)

#### Example 2 of Long Exposure

EXT HD Continuous signal: 15.734 kHz (XC-ST50/ST30), 15.625 kHz (XC-ST50CE/30CE) Allowable frequency value ±1%



EXT VD VD interval(T): 262.5H or more (XC-ST50/ST30), 312.5H or more (XC-ST50CE/30CE) and 1 second or less (Recommended)



Odd and even fields are determined by the phase of the EXT HD/VD signal input from external equipment.

# FRAME IMAGE OUTPUT WITH STROBE LIGHT

A full frame image with vertical resolution of 485 lines (XC-ST50/ST30) or 575 lines (XC-ST50CE/ST30CE) can be obtained with a strobe light by firing the strobe when the exposure time of the two fields overlap.


#### Timing and conditions

<Timing chart by restart/reset>

**EXT HD**  $Continuous\ signal:\ 15.734\ kHz\ (XC-ST50/ST30),\ 15.625\ kHz\ (XC-ST50CE/30CE)\quad Allowable\ frequency\ value\ \pm1\%$ 



**EXT VD** VD: XC-ST50/ST30 (1/60 sec), XC-ST50CE/30CE (1/50 sec) Four or more VD pulses are required.




Odd and even fields are determined by the phase of the EXT HD/VD signal input from external equipment. Avoid lighting the scene during the light-emitting inhibit zone (see Note below). (The field is transfered to the storage area of the CCD, so it can be read out.)


Note: For best performance, it is recommended not to use a flash between VD and VD + 10H (XC-ST50/ST30)/ 16H (XC-ST50CE/ST30CE).

# OUTPUT WAVEFORM TIMING CHART (XC-ST50 (EIA)/XC-ST30 (EIA))

#### ○ Timing chart of horizontal output waveform




#### ○ Timing chart of vertical output waveform (2:1 interlaced frame integration)




# ■ OUTPUT WAVEFORM TIMING CHART (XC-ST50 (EIA)/XC-ST30 (EIA)) =

○ Timing chart of vertical output waveform (2:1 interlaced field integration)




# OUTPUT WAVEFORM TIMING CHART (XC-ST50CE (CCIR)/XC-ST30CE (CCIR)) =

#### **○ Timing chart of horizontal output waveform**




#### ○ Timing chart of vertical output waveform (2:1 interlaced frame integration)




# — OUTPUT WAVEFORM TIMING CHART (XC-ST50CE (CCIR)/XC-ST30CE (CCIR))

○ Timing chart of vertical output waveform (2:1 interlaced field integration)



#### For setting the shutter speed using TRG width

- **♦ HD/VD input** 
  - Continuous HD/VD input




- \*1: This is a signal input from external equipment. Be sure to input both HD and VD signals in this case.
- \*2: Exposure time Te Te = Trigger width + 97  $\mu$ s (XC-ST50/30) Te = Trigger width + 120  $\mu$ s (XC-ST50CE/30CE) (The trigger width should be between 2  $\mu$ s and 1/4 s)
- \*3: Normal operation is engaged when the trigger high period exceeds 1/3sec. The external trigger shutter operation is engaged when the trigger pulse goes "low". In this case, the area between the falling edge of a trigger pulse and the subsequent 50 ms period is an external trigger input inhibition area. During the trigger inhibit period, an input trigger may be missed.
- \*4: In all cases the WEN signal indicates when a valid image is available. Normally, an image is output after the external falling edge. If the falling edge of the trigger is very close to the falling edge of the external VD, there may be a delay of 1VD in the output. The period of uncertainty is when the falling edge of VD is between 65 μs before or 10 μs after the falling edge of the trigger.
- ★5: When the external trigger shutter mode changes to normal operation mode, one WEN signal is output.

#### For setting the shutter speed using TRG width

#### **♦** HD/VD input


Continuous HD input and single VD input



- ★1: This is a signal input from external equipment. Be sure to input both HD and VD signals in this case. The phase of the VD signal must coincide with the falling edge of the HD signal during input operation.
- \*2: Exposure time Te Te = Trigger width + 97  $\mu$ s (XC-ST50/ST30) Te = Trigger width + 120  $\mu$ s (XC-ST50CE/ST30CE) (The trigger width should be between 2  $\mu$ s and 1/4 s)
- \*3: The normal operation state is engaged when the trigger high period exceeds 1/3 sec. After that the external trigger shutter operation is engaged when the trigger pulse goes "low". In this case, the area between the falling edge of a trigger pulse and the subsequent 50 ms period is an external trigger input inhibition area. During the trigger inhibit period, an input trigger may be missed.
- \*4: An external VD signal must be input between 10 μs and 100 ms from the falling edge of a trigger pulse (as shown by ① and ② in the figure). For the input (except described above), the operation cannot be ensured.
- ★5: When the external trigger shutter mode changes to normal operation mode, one WEN signal is output.

## For setting the shutter speed using TRG width


♦ No HD/VD input (Internal synchronization)



- \*1: This is a signal input from external equipment.
- \*2: Exposure time Te Te = Trigger width + 97  $\mu$ s (XC-ST50/ST30) Te = Trigger width + 120  $\mu$ s (XC-ST50CE/ST30CE)
- \*3: Normal operation is engaged when the high period exceeds 1/3 sec. After that, the external trigger shutter operation is engaged when the trigger pulse goes "low". In this case, the area between the falling edge of a trigger pulse and the subsequent 50 ms period is an external input inhibition area. During the trigger inhibit period, an input trigger may be missed.
- \*4: An internal VD signal is output by setting the INT/EXT switch on the rear panel to INT.
- \*5: During external trigger shutter operation, an image is output when an internal VD signal falls after a trigger pulse falls (as shown by ① and ② in the figure). However, if the time (T in the figure) between the falling edges of a trigger pulse and internal VD signal is under 10 μs, an image is output when the internal VD signal or the next internal VD signal falls (as shown by ③ in the figure). (In this case, an image is output when the next internal VD signal falls.) An image and WEN signal are always output together. For more details, refer to the WEN signal.
- ★6: When the external trigger shutter mode changes to normal operation mode, one WEN signal is output.

## For setting the shutter speed using DIP switch

- **♦ HD/VD input** 
  - Continuous HD/VD input




- ★1: This is a signal input from external equipment. The period of a continuous VD signal is prescribed as one field. Both HD and VD signals must be input.
- \*2: As shown in the table on page 7, exposure time Te is determined by the DIP switch setting.
- \*3: Normal operation is engaged when the high period exceeds 1/3 sec. After that, the external trigger shutter operation is engaged when the trigger pulse goes "low". In this case, the area between the falling edge of a trigger pulse and the subsequent 50 ms period is an external input inhibition area. During the trigger inhibit period, an input trigger may be missed.
- \*4: An image is output when an external VD signal falls 10 ms or more after a trigger pulse rises (shown by ② and ③ in the figure). If the time (T in the figure) between the falling edges of a trigger pulse and external VD signal is under 10 ms, an image is output when the external VD signal or the next external VD signal falls (as shown by ① in the figure). (In this case, an image is output when the next external VD signal falls.) An image and WEN signal are always output together. For more details, refer to the WEN signal.

## For setting the shutter speed using DIP switch

#### **♦** HD/VD input


. Continuous HD input and single VD input



- ★1: This is a signal input from external equipment. Both HD and VD signals must be input. The phase of the VD signal must coincide with the falling edge of the HD signal.
- \*2: As shown in the table on page 7, exposure time Te is determined by the DIP switch setting.
- \*3: Normal operation is engaged when the high period exceeds 1/3 sec. After that, the external trigger shutter operation is engaged when the trigger pulse goes "low". In this case, the area between the falling edge of a trigger pulse and the subsequent 50 ms period is an external input inhibition area. During the trigger inhibit period, an input trigger may be missed.
- \*4: An external VD signal for 10 ms to 110 ms must be input from the rising edge of a trigger pulse (as shown by ① and ② in the figure). For the input except described above, the operation cannot be ensured.


## For setting the shutter speed using DIP switch

♦ No HD/VD input (Internal synchronization)




- ★1: This is a signal input from external equipment.
- ★2: As shown in the table on page 7, exposure time Te is determined by the setting of a DIP switch.
- \*3: Normal operation is engaged when the high period exceeds 1/3 sec. After that, external trigger shutter operation is engaged when the trigger pulse goes "low". In this case, the area between the falling edge of a trigger pulse and the subsequent 50 ms period is an external input inhibition area. During the trigger inhibit period, an input trigger may be missed.
- \*4: An internal VD signal is output by setting the INT/EXT switch on the rear panel to INT.
- ★5: An image is output when an internal VD signal falls 10 ms or more after a trigger pulse rises (as shown by ② and ③ in the figure). If the time (T in the figure) between the falling edges of a trigger pulse and internal VD signal is under 10 ms, an image is output when the internal VD signal or the next internal VD signal falls (as shown by ① in the figure). In this case, an image is output when the next internal VD signal falls. An image and WEN signal are always output together. For more details, refer to the WEN signal. (The falling edge of an internal VD signal is the same in phase as the beginning of an equalizing pulse in a SYNC V area.)

#### For setting the shutter speed using TRG width



- \*1: This is a signal input from external equipment. The trigger interval should be the trigger pulse width + 1 field + 2H period or more. The trigger interval shorter than described above cannot be ensured. If a trigger pulse is not input under the prescribed conditions, please wait several V before re-entering a trigger pulse.
- $\star$ 2: Exposure time Te Te = Trigger width + 97 μs (XC-ST50/ST30), Te = Trigger width + 120 μs (XC-ST50CE/ST30CE) (The trigger width should be between 2 μs and 1/4 s)
- \*3: Normal operation is engaged when the high period exceeds 1/3 sec. After that, the external trigger shutter operation is engaged when the trigger pulse goes "low". In this case, the area between the falling edge of a trigger pulse and the subsequent 50 ms period is an external input inhibition area. During the trigger inhibit period, an input trigger may be missed.
- ★4: A VD signal is generated 1H to 2H after a trigger pulse falls, and an image is output in synchronization with the VD signal.
- ★5: When the external trigger shutter mode changes into the normal operation mode, a WEN signal is output.


#### For setting the shutter speed using DIP switch



- \*1: This is a signal input from external equipment. The trigger interval should be the shutter speed (DIP switch) + 1 field + 2H period or more. A trigger interval shorter than described above cannot be ensured. If a trigger pulse is not input under the prescribed conditions, please wait several V before re-entering a trigger pulse.
- ★2: As shown in the table on page 7, exposure time Te is determined by the DIP switch setting.
- \*3: Normal operation is engaged when the high period exceeds 1/3 sec. After that, the external trigger shutter operation is engaged when the trigger pulse goes "low". In this case, the area between the falling edge of a trigger pulse and the subsequent 50 ms period is an external input inhibition area. During the trigger inhibit period, an input trigger may be missed.
- \*4: After a period set by a DIP switch from the rising edge of the trigger, an image is output.


# - DIMENSIONS

# ■ XC-ST50/50CE XC-ST30/30CE




# SPECTRAL RESPONSE CHARACTERISTICS (TYPICAL VALUE)

#### **XC-ST50/ST30**



# — COMPARISON OF SPECTRAL RESPONSE CHARACTERISTICS — (TYPICAL VALUE)

#### ■ XC-75/73 and XC-ST50/ST30



# **WARIOUS LENS SELECTION :**

The following shows the various lens specifications of the accessories available.

# ■ XC-ST50/50CE and XC-ST30/30CE compatibility

#### List of C-Mount Lenses

Model name	VLC-08YM	VLC-12YM	VLC-16Y-M	VLC-25Y-M	VLC-50Y-M	
Focal distance (mm)		8	12	16	25	50
Maximum aperture ratio		1: 1.4	1: 1.8	1: 1.4	1: 1.6	1: 2.8
Operation	Iris	Manual	Manual	Manual	Manual	Manual
Operation	Focus	Manual	Manual	Manual	Manual	Manual
Field angle	Field angle 1/2" CCD		29.6°×22.4°	22.6°×17.0°	14.6°×11.0°	7.3°×5.5°
(Horizontal x vertical)	(Horizontal x vertical) 1/3" CCD		22.4°×16.9°	17.0°×12.8°	11.0°×8.2°	5.5°×4.1°
MOD (mm)		207	208	289	204	438
	XC-ST50	181×132.8	125.2×92.1	119.4×88.5	52.1×38.8	49.2×37
Image pickup range during maximum proximity	XC-ST50CE	181.3×133.3	125.5×92.5	119.6×88.8	52.1×38.9	49.7×37.1
(horizontal × vertical) (mm)	XC-ST30	136.8×100	94.7×69.6	90×66.8	39.4×29.3	37.2×27.9
	XC-ST30CE	137×100.3	94.8×69.6	90.4×66.9	39.4×29.3	37.5×27.9
Back focus (mm)		11.54	10.99	12.5	11.6	22.1
Flange back (mm)	Flange back (mm)		17.526	17.526	17.526	17.526
Mass (g)		40	40	50	42	50

MOD: Minimum object distance between the tip of the lens body and the object

Sony reserves the right to change specifications of the products and discontinue products without notice.

Technical information contained herein is for reference only and does not convey any license by any implication or otherwise under any intellectual property right or other right of Sony or third parties.

Sony cannot assume responsibility for any right infringements arising out of the use of this information.

#### Sales Office:

Japan http://www.sony.co.jp/ISP/

Sony Corporation

4-14-1 Asahi-cho,Atsugi-shi, Kanagawa,243-0014 Japan Tel: +81-46-227-2346 Fax: +81-46-227-2347 Tel: +81-46-230-5873 Fax: +81-46-230-6243

USA

http://www.sony.com/videocameras

Sony Electronics Inc.

HQ

1 Sony Drive Park Ridge, NJ 07656

Tel: +1-800-686-7669

Canada

Sony of Canada Ltd.

115 Gordon Baker Rd, Toronto, Ontario M2H 3R6 Tel: +1-416-499-1414 Fax: +1-416-497-1774 XC-ST50/50CE XC-ST30/30CE



Europe

http://www.pro.sony-europe.com/ISP

Sony Broadcast & Professional

HQ

15, rue Floreal 75831 Paris Cedex 17, France Tel: +33-1-55-90-35-11 Fax: +33-1-55-90-35-17

Germany

Hugo-Eckener-Str. 20, 50829 Koln

Tel: +49-221-5966-322 Fax: +49-221-5966-491

France

15, rue Floreal 75831 Paris Cedex 17

Tel: +33-1-55-90-41-62 Fax: +33-1-55-90-13-57

UK

The Heights, Brooklands, Weybridge, Surrey KT13 0XW Tel: +44-1932-816-340 Fax: +44-1932-817011

Nordic

Per Albin Hanssons vag 20 S-214 32 Malmo Sweden Tel: +46-40-190-800 Fax : +46-40-190-450

Italy

Via Galileo Galilei 40 I-20092 Cinisello Balsamo, Milano Tel: +39-02-618-38-431 Fax: +39-02-618-38-402

